

GMM

Combo

Gmm – Oliosi una sfida ad “alta tecnologia”

*Combo
five axis saw and waterjet latest challenge at
Oliosi company in Verona*

Marmi Oliosi nasce nel 2006 da Leris Oliosi ed è da sempre laboratorio di riferimento nell'area di Verona.

Oggi Marmi Oliosi raggiunge un nuovo obiettivo nel suo percorso di continua innovazione tecnologica con l'aggiunta di uno specifico "Sistema" denominato "COMBO"

Tale sistema combinato fresa - waterjet è costituito da due macchine distinte che possono lavorare sia in modo completamente indipendente che in modo combinato con programmazione della lavorazione sulla fresa, taglio con disco sul banco fresa e successivo trasferimento in automatico dei pezzi sulla tavola waterjet per l'esecuzione di tagli curvi, foretti, scassi il tutto in un unico ciclo automatico e guidato da un unico sistema SW CAD di proprietà di GMM.

GMM and Marmi Oliosi strikes again, after being the reference customer in the Verona Area the established partnership GMM - Oliosi has achieved a new target, the recent installed "COMBO" a dual use machine fully automated where the combination of a Five axis saw and a Five axis Waterjet are gone together building the revised concept system for cutting stone and the rising new porcelain material.

The system is based on the concept of having two units working simultaneously but being driven from a single software the powerfully Gmm CAD.

With a unique interface the system performs diamond blade cutting then with the Patented Vacuum Head transfer the sawn piece in to the Waterjet Tank for internal cutting.



L'acquisizione di Techni Waterjet LTD società austriaca presente nel settore da più di trent'anni nella produzione di macchine a taglio ad acqua con tecnologie innovative e brevettate quali la testa a rotazione continua, e la pompa ad alta pressione servo-elettrica ha permesso a GMM leader mondiale nel campo delle fresa CNC di implementare questo innovativo sistema.

La società gestita da Erika Lucchese, moglie e primo supporto di Leris vede l'ingresso, nel 2014, della figlia Alexa che opera con estrema perizia sui macchinari GMM (Lexta 36, Tecna 36, Egil 36 CNC, Costa 86) e contribuisce alla creazione di un polo tecnologico di eccellenza in grado di soddisfare la domanda sempre più diversificata di designer italiani e mondiali che coinvolge oltre al marmo ed al granito anche la lavorazione di altri materiali quali agglomerati e ceramica.

Marmi Oliosi "the home of the Marble most advanced technology".

The two unit can work also independently in order to increase productivity and expand the range of products. Marmi Oliosi was founded in 2006 by Leris Oliosi under the impulse of his pure passion for shaping one of the most incredible material, Marble.

Since the beginning in the company was operating Erika Lucchese, wife and first Leris support, in 2012 the company was moved in a new facility and after the initial Gmm machines others were installed. Lately also Alexa, the daughter joined the company and this was further impulse for this family owned company toward the latest marble technology to satisfy the increasing demand of the Made in Italy designer. Today with the installation of the COMBO Marmi Oliosi is now the home of the Marble most advanced technology.

A cura di / By:

GMM
STONE MACHINERY